



Assembly Instruction Sheet For Item No.384 -1X : 4 - Tier CD/DVD Folding Shelf




Diag.1.

Step 1 :
Gently lean the closed folding shelf against the wall with a slight tilt to the back as per Diag. 1




Diag.2.

Step 2 :
Open side panels and while they are opened lower each shelf as per Diag. 2. Make sure each shelf rests on the metal clip one on each side of the side panels.



Diag.3.

Step 3 : Attach the leg supports to bottom the folding shelf by align the plastic pegs to each holes as per Diag.3.



Diag.4.

Step 4 : Stand the folding shelf to its upright position as per Diag.4.


CAUTION - To remove the folding shelf in the opened position, grab only the crossbars on the side panels.

The Package Contained :


Folding Shelf	1
Leg Supports	2

Missing Hardware?

Missing or parts replacement please
visit www.yushan.com/replacement
or call 1-312-895-4575
Do not return this product to the store.
Normally there is no charge for parts.



Diag.5.



ADDITION MANTEL TOP

When you need the mantel top shelf for 384-1X, just to attach the mantel top to the folding shelf by align the holes below the mantel top to the plastic pegs as per Diag.5.